




- Run NovaLCT-Mars, move the cursor over the *Advanced User Login (A)* and click the icon.




- Login with the password "admin".




- Then click *Calibration* icon.




4. *Enable/Disable Calibration* options is at bottom-left corner, there are three options: *Disable calibration , Chroma calibration and brightness calibration*.




5. Select *Disable calibration* and save for Disable calibration function.



6. After process finished, *saved successfully* notice will appear, select *ok* to end the disable calibration process.



7. After calibration finished, select *Chroma calibration* or *Brightness calibration* and *save* for enable calibration function.



8. After process finished, *saved successfully* notice will appear, select *ok* to end the enable calibration (chroma or brightness) process.

